Bellingham, WA

Radial Immunodiffusion Test For Quantitation of Goat IgG In Serum or Plasma

ATTENTION

Plate must be refrigerated and stored upside down. Also avoid near freezing temperatures. Accuracy can only be assured with proper storage.

1. Summary

Single radial immunodiffusion tests have evolved from the work of Fahey and McKelvey¹ and Mancini et al². They are specific for the various proteins in serum or other fluids and depend on the reaction of each protein with its specific antibody.

When the wells in antibody containing gels are completely filled with the antigen, the precipitin rings that develop after 10-20 hours at room temperature are measured. The diameter of the ring and the logarithm (base 10) of the protein concentration are related in a linear fashion. Using appropriate reference standards, the concentration of unknown samples may be measured.

Immunoglobulin G (IgG) is one of the first lines of defenses against encapsulated bacteria and streptococci.

2. Principle

Radial immunodiffusion is based on the diffusion of antigen from a circular well radial into a homogeneous gel containing specific antiserum for each particular antigen. A circle on precipitated antigen and antibody forms, and continues to grow until equilibrium is reached. The diameters of the rings are a function of antigen concentration. After overnight incubation, the zone diameters of reference sera are plotted against the logarithm (base 10) of the antigen concentration. If equilibrium is reached, the reference sera zone diameters are squared and plotted against their concentration (linear). At intervals in between, a linear relationship does not occur. Unknown concentrations are measured by reference to the standard curve.

3. Reagents

Radial immunodiffusion plates contain specific antiserum in agarose gel, 0.1M phosphate buffer pH 7.0, 0.1% sodium azide as bacteriostatic agent, I ug/ml amphotericin B as an antifungal agent. Plates also contain 0.002M ethylenediaminetetracetic acid. Store at refrigerator temperatures (2 to 8 C).

4. Specimen Preparation And Handling

- A. Collect whole blood without anticoagulant and allow to clot at room temperature.
- B. Separate serum by centrifugation at about 200 rcf within 2-3 hours after collection.
- C. Plasma may be used, but non-specific precipitation of fibrin may obscure precipitation rings. In addition, liquid anticoagulants such as ACD fluid will dilute the specimen.

5. Procedure

- A. Materials Provided
- 1. One Radial Immunodiffusion plate.
- 2. Directions for use.
- B. Materials Required
- 1. Blood collection tubes
- 2. Centrifuge (200rcf)
- 3. Microliter dispenser (5 microliters)
- 4. Reference sera (required if not provided in kit form)
- 5. Normal control sera (optional)
- 6. Measuring device -- calibrated in 0.1mm increments
- 7. Two cycle semi-logarithmic graph paper and/or linear

C. General

- 1. Do not overfill or underfill wells. An improperly filled well yields erroneous results and the same specimen should be placed in another well. Overfilling with a 5 microliter sample indicates that some gel shrinkage has occurred.
- 2. Reference serum zone diameters should be measured at the same time as test sera. If a delay in measurement is anticipated allow sufficient intervals between filling wells.
- 3. The time of filling each plate should be marked on the cover and if more than one plate is filled, they should be read in order of filling.
- 4. Excess moisture is required to prevent drying. Replace each plate in its plastic bag and reseal carefully before incubation.
- 5. Shrinkage of gel or oval shaped wells indicates drying and the plate should not be used.
- 6. If temperature fluctuations are anticipated, the plates in their bags may be incubated in an insulated container. Fluctuations in temperature may result in multiple precipitin ring formation.
- 7. Unused sections may be run at a later day if the plate has been stored at 2 to 8 C between incubations in its plastic bag. Check carefully for evidence of drying. Store upside down.
- 8. Rough granulation of the gel indicates freezing, plates should be discarded.

D. Performance Of Test

- 1. Remove plates from refrigerator to room temperature approximately 30 minutes before filling wells. Do not open bag until ready for use.
- 2. If excess moisture is present, remove plate from bag and remove cover until evaporation has dried the surface and wells. Replace cover until used.
- 3. For best results, three wells should be filled with reference sera for each plate. Location of each should be noted. Mix each vial of reference serum thoroughly.
- 4. Deliver specimen to well by placing the pipette tip at the bottom of the well. Allow the well to fill to the top of the agar surface. Avoid bubbles to ensure proper volume and diffusion of sample. Visualization may be aided by placing the plate on dark background. If practice is required, a used plate may be utilized.
- 5. More consistent results are obtained when wells are filled with a 5 microliter pipette.
 - 6. Mark time of completion on plate cover and replace cover.
 - 7. Replace plate in bag and reseal carefully.
- 8. Incubate plate upright on a flat surface at room temperature (20 24 C) for 16-20 hours for Overnight readings and over 48 hours for End Point readings. See C6 above.

E. Calibration

- 1. Using the reference sera provided in kits determine their ring diameters to the nearest 0.1mm.
- 2. Using 2 or 3 cycle semi-logarithmic graph paper, plot the concentration on the Y axis and the zone diameters on the linear or X axis for each protein for Overnight readings.
- 3. Using regular graph paper, plot the concentration on the X axis and the zone diameters squared on the Y axis for each protein for End Point readings.
- 4. Draw a straight line of "best fit" between the three points. A curved line usually indicates that the incubation time and/or temperature should be reduced for overnight values. For valid results, a smooth curve should be fitted to the points and control sera included for additional verification.

graph paper.

F. Quality Control

For consistent results and a comparison of lot to lot, day to day, and week to week variations, a "normal" and abnormal serum should be included each day. The diameters and concentrations obtained can be charted to determine means and standard deviations. For the same specimen, an appropriate series of wells on the same plate should yield diameters within 0.2mm of one another. Control sera should be freshly thawed or reconstituted.

6. Results

Determine the concentration of each unknown of specimen protein by reading its zone diameter on the reference curve and the corresponding concentration from the X axis. Zone diameter must be squared for End Point calibration.

- 7. Interpretation Of Results And Limitation Of The Procedure
- A. When an unknown diameter exceeds that of the top standard, the specimen should be diluted with saline and rerun.
- B. When an unknown diameter is smaller than that of the lowest standard, its concentration should be reported as "less than" the concentration of the reference serum. If available, "low level" radial immunodiffusion plates may be utilized.
 - C. Lack of a precipitin ring may be due to:
 - 1. Sample not applied to well
 - 2. A concentration too low to be detected by the method
- 3. A concentration too high, resulting in the formation of soluble complexes, which are not precipitated

8. Performance Characteristics

A. For investigational use only. The performance characteristics of this product have not been established.

9. References

- 1. Fahey, J.L. and McKelvey, E.M. Quantitative determination of serum immunoglobulins in antibody agar plates. J. Immunol. 94,84, 1965.
- 2. Mancini, G., Carbonara, A.O. and Heremans, J.F. Immunochemical quantitation of antigens by single radial immunodiffusion. Immunochemistry 2, 235, 1965.
- 3. Stokes, C, Bourne JF. Mucosal immunity. In: Halliwell REW, Gorman NT, eds. Veterinary clinical immunology. Philadelphia: WB Saunders Co, 1989.

TRIPLE J FARMS

777 Jorgensen Place
Bellingham, Washington 98226
360-398-9512 http://www.kentlabs.com

